



# Database Search Tool & Thumbnail Preview Image Gallery

VISIONx INC.  
www.visionxinc.com

## Powerful & Easy To Use

You can use VisionGauge's® "Database Search" tools to call up all of the reports in VisionGauge's® report database that contain a specific search string (e.g. a date, an evocative keyword, a specialized term, etc...). Searches can either be case sensitive or not. These enhanced "Database Search" tools work seamlessly with VisionGauge's® integrated Report Generator and Database.

To carry out a search, simply type in a search string and VisionGauge® shows you all of the reports in which it can be found, sixteen at a time. For each matching report, VisionGauge's® "Database Search" tools display a thumbnail preview image, along with the two "key field" strings. Then, when you click on the image of the report that you are looking for, VisionGauge® retrieves the entire report (including both the image and the data) and loads it into the Report Generator.

The screenshot shows the VisionGauge software interface. A search results dialog box is open, titled "These reports match your search criteria - Please make your selection...". The dialog displays 16 thumbnails arranged in a 4x4 grid, each with a corresponding report ID. The report IDs are: OADDB-CF6 CIRC-01, 98SFGV-V2 HC-2SA45B, WO-KK265 IMMN00A69, NSTL-022 TEST-1023, PCB-04 CS-227, CAL-01 0.040 STANDARD, HARDNESS TESTING-01 KNOOP INDENT, 9599R-T2 COPPER PIPE X-SECT., 78883--D COAX VIEW-01, FT778-GMC SMT COMPONENT, PCB-0023 FLIP CHIP, and DB-BD-680923 DRILL-01. Navigation buttons include "< Previous", "Cancel", "Help", and "Next >".

Reading image from file C:\vision\Current\Images\Threads-01.bmp  
Finished